










- D** Montageanleitung
- NL** Handleiding voor de montage
- TR** Montaj talimatı
- FR** Instructions de montage
- CZ** Montážní návod
- HU** Összeszerelési útmutató
- GB** Assembly instructions
- PL** Instrukcja montażu
- RU** Инструкция по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- SK** Montážny návod












A	B	C (mm)		D
1	S215-132	361	303	1/2
2	S215-133	361	303	1/2
3	S215-134	328	246	1/2
4	S215-329	1360	262	1/2
5	S215-349	1360	301	1/2
6	S215-416	1360	42	1/2
7	S215-561	494	292	2/2
8	S215-720	460	326	2/2
9	S215-721	460	326	2/2
10	S215-907	1370	347	1/2




















7



8

**Pflegehinweis!**

Bitte nur mit einem Staubtuch  
(kein Microfasertuch) oder  
einem feuchten Lappen reinigen.  
KEINE scheuernden Putzmittel  
verwenden!

**Wskazówka dotycząca pielęgnacji!**

Proszę czyścić tylko suchą lub lekko  
wilgotną szmatką do kurzu. Nie używać  
żadnych środków szorstkich!

