









TOUCH S77-REG1W1D2S/20/8



A	B	C	D
1	S77-002	796	156
2	S77-003	1580	396
3	S77-004	396	1580
4	S77-101	1586	396
5	S77-102	1586	396
6	S77-104	322	396
7	S77-105	1586	392
8	S77-201	800	420
9	S77-202	800	420
10	S77-203	800	420
11	S77-301	374	380
12	S77-302	375	392
13	S77-303	375	383
14	S77-501	350	120
15	S77-502	350	120
16	S77-503	735	120
17	S77-901	745	350
18	S77-903	787	381
19	S77-9901	1623	787




6x a58	6x b22	4x c235	12x d1	16x d5	24x f1	8x f25	4x j2	4x k55
80x l1	2x o27	16x p1	4x p25	2x p39	6x p44	6x p51	8x p6	6x p9
24x r1	8x r15	32x r16	16x s2	2x t19	4x w4	1x n26/1	1x p38	







7



8

