
















A

Senso

K31-D-60/207

A	B	C	D
1	K31-1007	1966	560 1/1
2	K31-1008	1966	560 1/1
3	K31-3002	567	510 1/1
4	K31-3023	567	533 1/1
5	K31-3201	567	533 1/1
6	K31-9012	1961	577 1/1



12x Ø5x17 mm d3	6x Ø7x50 mm e1	32x Ø8x30 mm f1	2x Ø10x50 mm f35	2x k66 4	4x k74 1	4x k74 2	4x k74 3	4x L-73 mm k74 5
25x l1	2x 86x21x15 1.5 n14 2	4x Ø3,5x13 mm p1	2x Ø5x60 mm p17	16x Ø4x13 mm p28	5x CLIP BLUMOTION a146	5x b31	6x M4x12 mm j45 1	
4x Ø3,5x16 mm p38	18x Ø15x12 mm #16 r1	18x 20 11 r42	1x z1		3x j45 2	4x silikon o21	10x Ø3,5x15 mm p51	