















A

Senso

K31-DC-60/230

A	B	C	D	
1	K31-1050	2196	560	1/1
2	K31-1051	2196	560	1/1
3	K31-3025	567	550	1/1
4	K31-3139	567	550	1/1
5	K31-3146	567	550	1/1
6	K31-9017	2191	577	1/1



6x Ø7x50 mm e1	24x Ø8x30 mm f1	2x Ø10x50 mm f35	2x k66 4	5x k74 1	5x k74 2	5x k74 3	5x L-73 mm k74 5	15x l1
2x 86x21x15 1,5 n14 2	4x Ø3,5x13 mm p1	2x Ø5x60 mm p17	20x Ø4x13 mm p28	4x Ø3,5x16 mm p38	2x CLIP BLUMOTION a146	2x b31	6x M4x12 mm j45 1	3x j45 2
12x Ø15x12 mm #16 r1	12x 20 11 r42	1x z1			2x n176	6x silikon o21	4x Ø3,5x15 mm p51	8x Ø3,5x16 mm p38