

























A

Senso

K31-DP-60/230

A	B	C	D
1	K31-1131	2196	560
2	K31-1132	2196	560
3	K31-3001	567	515
4	K31-3002	567	510
5	K31-3024	567	515
6	K31-3047	567	515
7	K31-9034	711	577
8	K31-9062	877	577



A

Senso

K31-DP-60/230

A	B	C	D
1	K31-1131	2196	560 1/1
2	K31-1132	2196	560 1/1
3	K31-3001	567	515 1/1
4	K31-3002	567	510 1/1
5	K31-3024	567	515 1/1
6	K31-3047	567	515 1/1
7	K31-9034	711	577 1/1
8	K31-9062	877	577 1/1
9	K31-9092	607	577 1/1



A	B	C	D
10	K31-5029	565	505 1/1

