




A

Senso

K31-DSWT-45/207

A	B	C	D
1	K31-1192	1966	560
2	K31-1193	1966	560
3	K31-3005	417	533
4	K31-3006	417	533
5	K31-3007	417	510
6	K31-9003	1961	427



4x Ø5x17 mm d3	6x Ø7x50 mm e1	24x Ø8x30 mm f1	2x Ø10x50 mm f35	4x k74\1	4x k74\2	4x k74\3	4x L-73 mm k74\5	15x l1
2x 86x21x15\5 n14\2	2x Ø5x60 mm p17	16x Ø4x13 mm p28	4x Ø3,5x16 mm p38	12x Ø15x12 mm #16 r1	5x CLIP BLUMOTION 125 a171	5x b31	6x M4x12 mm j45\1	3x j45\2
12x z0\11 r42	1x z1			2x k66\4	4x silikon o21	4x Ø3,5x13 mm p1	10x Ø3,5x15 mm p51	