














A

Senso

K31-DSWT-60/207

A	B	C	D
1	K31-1192	1966	560 1\1
2	K31-1193	1966	560 1\1
3	K31-3002	567	510 1\1
4	K31-3023	567	533 1\1
5	K31-3201	567	533 1\1
6	K31-9012	1961	577 1\1



4x Ø5x17 mm d3	6x Ø7x50 mm e1	24x Ø8x30 mm f1	2x Ø10x50 mm f35	4x k74\1	4x k74\2	4x k74\3	4x L-73 mm k74\5	15x l1
2x 86x21x151,5 n14\2	2x Ø5x60 mm p17	16x Ø4x13 mm p28	4x Ø3,5x16 mm p38	12x Ø15x12 mm #16 r1	5x CLIP BLUMOTION 125 a171	5x b31	6x M4x12 mm j45\1	3x j45\2
12x z011 r42	1x z1				2x k66\4	4x silikon o21	4x Ø3,5x13 mm p1	10x Ø3,5x15 mm p51